



#20712

Дротовий контролер

Контролер для ПК і PlayStation 3 зі зручною ручкою для ігор

Key features

- Кабель 3 м
- 13 кнопок, 2 джойстики та перемикач напрямків
- Натискні перемикачі та кнопки (тільки для PS3)
- Гумове покриття для зручного використання
- Індикатори контролера та кнопка «Дім»
- Перемикач X-Input/DirectInput для повної підтримки ігор



What's in the box

- Ігровий контролер
- Посібник користувача
- Наклейка ігрової тематики

System requirements

- ПК/ноутбук з ОС Windows 10, 8 або 7
- PlayStation 3
- Порт USB



3 METER
CABLE

13

RESPONSIVE
BUTTONS



DIRECT INPUT-
X INPUT

GENERAL

Driver needed	False	Height of main product (in mm)	65 mm
Width of main product (in mm)	150 mm	Depth of main product (in mm)	110 mm
Total weight	253 g		

CONNECTIVITY

Connection type	Wired	USB version	1.0
Cable length main cable	300 cm		

INPUT

Power source	USB
---------------------	-----

AUDIO

Built-in speaker	False	Headphone connection	False
-------------------------	-------	-----------------------------	-------

CONTROL

Controls	Directional pad	Number of buttons	13
Shoulder buttons	True	Trigger buttons	True
Pressure sensitive buttons	True	Analogue stick	True
Turbo fire	False	Vibration	Vibration feedback
x-input / direct input	D-input, x-input		

COMPATIBILITY

Compatible Device Types	Gaming console, laptop, pc	Compatible Consoles	PS3
Compatible Software Platforms	Windows		

FEATURES

Software	False
-----------------	-------



PRODUCT VISUAL 1



PRODUCT ESHOT 1



PRODUCT VISUAL 2



PRODUCT TOP 1



PRODUCT SIDE 1



LIFESTYLE VISUAL 1



PACKAGE VISUAL 1



PACKAGE FRONT 1