



Cordless Lawn Mower

GE-CM 36/34-1 Li-Solo

Item No.: 3413226 Ident No.: 11019 Bar Code: 4006825645026

The Einhell Cordless Lawn Mower GE-CM 36/34-1 Li-Solo offers complete freedom from cables when looking after your lawn. PXC batteries can be used in all the devices in this successful system range from Einhell. The cutting height can be adjusted to five levels from 25 to 65 mm. The handles are ergonomically designed. The aluminum long handle is lightweight, sturdy, height-adjustable and can be folded for practical, easy storage. The integrated carry handle makes the unit easy to transport. The grass basket has a capacity of 30 liters and comes with a filling level indicator. Two 18 V batteries are required for operation. PXC batteries and charger are available separately, for example as a practical starter set.

WER X-CHANGE

Features & Benefits

- Member of the Power X-Change family, 2x18V batteries necessary
- Central cutting height adjustment, 5 levels
- Working without fatigue thanks to ergonomically shaped handle
- Height-adjustable long handle
- Space saving storage thanks to foldable long handle
- Stable and lightweight aluminium-long handle
- Integrated carry-handle for easy transport
- Filling level indication from the grass collection box
- Wide wheels with lawn-friendly running surface
- Supplied without battery and charger (available separately)

Technical Data

- Idle speed
- Cutting width
- Cutting height adjustment
- Capacity of catching device
- Wheel diameter front
- Wheel diameter rear

Logistic Data

- Gross weight (kg)
- Product weight (kg)
- Dimensions single packaging
- Pieces per export carton
- Gross weight export carton
- Dimensions export carton
- Container quantity (20"/40"/40"HC)

3400 min^-1 33.5 cm 5 | 25-65 mm | central 30 L 150 mm 180 mm

14.65 11.9 755 x 450 x 380 mm 1 Pieces 14.65 kg 760 x 440 x 380 mm 234 | 468 | 546









Available as special accessories



Ersatzmesser GE-CM 33 Li+36/34 Lawn Mower Accessory Item No.: 3405452 Bar Code: 4006825610611 Einhell Accessory





18V 4-6Ah Multi-Ah PXC Plus Battery Item No.: 4511502 Bar Code: 4006825644210 Einhell Accessory

2x 3,0Ah & Twincharger Kit PXC-Starter-Kit Item No.: 4512083

Bar Code: 4006825638509

Einhell Accessory



18V 4,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 Einhell Accessory



18V 5,2Ah Power X-Change Plus Battery Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory









Bar Code: 4006825613698 Einhell Accessory 18V 4,0Ah Power X-Change Battery

Power X-Boostcharger 6A Charger Item No.: 4512064 Bar Code: 4006825629019

18V 3,0Ah Power X-Change Plus Battery Item No.: 4511501

Bar Code: 4006825644197

18V 3,0Ah PXC Starter Kit PXC-Starter-Kit

Einhell Accessory

Einhell Accessory

Item No.: 4512041

Battery Item No.: 4511396 Bar Code: 4006825610376 Einhell Accessory

Power X-Twincharger 3A Charger Item No.: 4512069 Bar Code: 4006825629729 Einhell Accessory

Battery-Running-Times

One Battery for All	lawn mowing ¹
	(m²)
1.5 Ah	150
2.0 Ah	200
2.5 Ah	250
3.0 Ah	300
4.0 Ah	400
5.2 Ah	500
6.0 Ah	600

For best performance select a battery with at least 2.5 Ah

Test setup:

1) -