

Trust

USER GUIDE




www.trust.com/22193/faq




NOMAD | Gamepad
For PC & PS3

1.




2.

* PC only




X-input

D-input



3.



1X = TURBO
 2X = AUTO TURBO
 3X = CLEAR

4.

* PC only

WINDOWS 7



WINDOWS 8/10



Control panel

Devices and Printers

(a)

(b)

(c)

