

18V ONE+™ Cordless Garden Cultivator (Bare Tool) RY18CVA-0

RYOBI



- Use Ryobi's cultivator to create healthy soil and improve plant growth in your garden, allotment, or anywhere
- Three speed settings are ideal for a variety of applications
- Tool-free adjustment from four tines to two tines for narrower cultivating between rows or smaller patches
- Adjustable auxiliary handle for comfort over extended use
- Easily lift the guard to quickly clear debris from the tines



Power	18V
Cultivating width [cm]	20
Cultivating depth [cm]	10
Number of tines	4
Tine speed [rpm]	300, 250, 200
Weight with battery pack (EPTA) (kg)	5.2
Article Number	5133005047
Battery pack capacity (Ah)	-
Charger included	No
EAN Code	4892210189400
No. of batteries supplied	0
Sound pressure level (Lpa)(dB(A))	75.8
Sound pressure level uncertainty (dB(A))	3
Vibration level (m/s ²)	1.35
Vibration uncertainty (m/s ²)	1.5
Weight (without battery) (kg)	4.8



*Registration required for extension from 2-3 years. Please visit our site for full [T&C's](#)