



Large wheels exert less stress on the lawn. The product is supplied with a rechargeable battery and a system charger.



**Cordless Lawn Mower** 

**GE-CM 18/30 Li (1x3.0Ah)** 

Item No.: 3413155

Ident No.: 11017

Bar Code: 4006825629163

The Einhell GE-CM 18/30 Li cordless lawn mower is a powerful helper for maintaining lawns. Recommended for lawn areas up to 150m². The rechargeable battery from the Power X-Change family can be used in all the devices from the system series. Three LEDs show the charge status at a glance. For a long service life the mower has an Einhell brushless motor and a high-quality impact-resistant plastic housing. Practical features include the folding long handle for compact storage, the integrated carry handle for easy transportation and the 3-level axial cutting height adjustment facility.

-CHANGE

## Features & Benefits

- -Battery system Power X-Change
- -Battery capacity indicator with 3 LEDs
- -Accu can be used for all the tools in the Power X-Change family
- -System charger included
- -Einhell Brushless Motor
- -Axial cutting height adjustment, 3 levels
- -Long handle folding
- -Integrated carry-handle for easy transport
- -Grass protecting, large wheels
- -High quality, blow tough plastic housing
- -Recommended for lawn areas up to 150 m<sup>2</sup>

## **Technical Data**

- Accumulator 18 V | 3 Ah | Li-Ion

- Charging time 2h

- Idle speed 3300 min^-1 - Cutting width 30 cm

- Cutting height adjustment 3 settings | 30-70 mm | axial

wheel

- Capacity of catching device 25 L - Wheel diameter front 14 cm - Wheel diameter rear 14 cm

## **Logistic Data**

- Product weight 8.56 kg - Gross weight single packaging 10.59 kg

- Dimensions single packaging 605 x 395 x 375 mm

- Pieces per export carton 1 Pieces - Gross weight export carton 10.59 kg

595 x 385 x 310 mm - Dimensions export carton - Container quantity (20"/40"/40"HC) 312 | 642 | 749





















## Available as special accessories



Ersatzmesser GE-CM 18/30 Li Lawn Mower Accessory Item No.: 3404553 Bar Code: 4006825633092 Einhell Accessory



18V 3,0 Ah Power-X-Change Battery Item No.: 4511341 Bar Code: 4006825590593 Einhell Accessory



18V 4,0 Ah Power-X-Change Battery Item No.: 4511396 Bar Code: 4006825610376 Einhell Accessory



18V 3,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512041 Bar Code: 4006825613698 Einhell Accessory



18V 4,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 Einhell Accessory



18V 2,6Ah P-X-C Plus Battery Item No.: 4511436 Bar Code: 4006825616590 Einhell Accessory



18V 30min Power-X-Change PXC-Charger Item No.: 4512011 Bar Code: 4006825587029 Einhell Accessory



18V 5,2 Ah P-X-C Plus Battery Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory